



Perry Fiberglass Products, Inc.

LEADERS IN FIBERGLASS REINFORCED PLASTIC DUCT PRODUCTS

33660 PIN OAK PKWY, AVON LAKE, OH 44012 PHONE 440-930-7701 FAX 440-930-7717 www.PerryFiberglass.com

UNDERGROUND INSTALLATION PROCEDURES

Perry's Underground duct is simply laid on a bed of dry sand or pea gravel, joined with an internal galvanized sleeve which is sealed in place with Mastic and polyethylene-backed butyl rubber tape.

Encasement in concrete is not necessary. With sheet metal register boots subsequently in place and sealed, and then covered with sand or gravel or concrete, the floor slab may be poured with no delay or tie down.

Note: Installation per ACCA manual No. 4

